



721 W. Monroe St. New Bremen, Ohio 45869 Ph. 419-629-1969 Fax. 419-629-1912  
haganstreetrods@yahoo.com Haganauto.com

## Serious Suicide Hinges Quick Set UP Tips

- 1 Hinge pins must be on same axis
- 2 Receiver tubes must be braced at the back
- 3 Install receiver tubes so hinge arms set just inside inner door skin
- 4 Hinge arms and mount pockets must not interfere with door glass channel
- 5 Watch DVD and understand the parameters below before starting the project

Dimension (B) must be larger than dimension (A) to keep door from binding. Align the hinge receiver tube with the face of the pillar. You can trim away any area of the tube to keep it flush with the pillar. Dimension C is a minimum of  $\frac{1}{2}$ ". Dimension (A) must not exceed 2".

