tech questions: info@haganauto.com



1: Remove bulb from lamp housing



2: Peel paper off black butyl tape.



3: Slip LED through hole and into the bottom of the housing. Align and press in place.



4: You must trim bottom flange of bulb to allow clearance for the LED wires to exist the housing.

Www.haganauto.com 888-464-2426



Part code: hLTS-LED

LED Signal / Marker Light Installation Instructions





5: Re-install the bulb into the housing. Be careful not to pinch the new LED wires.

